

CLASSIC CREDENZA ASSEMBLY INSTRUCTIONS

Boltz Steel Furniture | 235 Tilk Rd | Conway, AR 72032 | 877.804.7650 | info@boltz.com



STEP 1. Lay the top upside down so that the threaded studs are pointing up. Take care not to scratch the product or the floor surface. Place the legs on the top, so that the oval holes go over the threaded studs. Attach legs to top using acorn nuts.



STEP 2. Place the floor caps upside down on the legs and attach them to the legs with the 1/2" bolts and acorn nuts. The bolts will be inserted from the bottom, so that the acorn nuts will be visible when completed.



STEP 3. Carefully turn the credenza over so that it is sitting upright. Place the included rubber bumperettes on the top. Place the glass on the top, and assembly is complete!



Fully Assembled Classic Credenza

PARTS LIST: (Extra pieces of hardware may be included)



LEG



FLOOR CAP



1/2" BOLT



ACORN NUT



BOLTZ WRENCH



ALLEN WRENCH



CREDENZA TOP